

HIMatrix

Safety-Related Controller

F30 Manual



HIMA Paul Hildebrandt GmbH + Co KG
Industrial Automation

All HIMA products mentioned in this manual are protected by the HIMA trade-mark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the CD-ROM and our website <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2010, HIMA Paul Hildebrandt GmbH + Co KG

All rights reserved

Contact

HIMA Address

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Tel: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com

Revision index	Revisions	Type of Change	
		technical	editorial
1.00	Added: Configuration with SILworX	X	X
1.01	Deleted: Chapter <i>Monitoring the Temperature State</i> displaced into the system manual		X

Table of Contents

1	Introduction	7
1.1	Structure and Use of this Manual	7
1.2	Target Audience	8
1.3	Formatting Conventions	9
1.3.1	Safety Notes	9
1.3.2	Operating Tips	10
2	Safety	11
2.1	Intended Use	11
2.1.1	Environmental Requirements	11
2.1.2	ESD Protective Measures	11
2.2	Residual Risk	12
2.3	Safety Precautions	12
2.4	Emergency Information	12
3	Product Description	13
3.1	Safety Function	13
3.1.1	Safety-Related Digital Inputs	13
3.1.1.1	Reaction in the Event of a Fault	14
3.1.1.2	Line Control	14
3.1.2	Safety-Related Digital Outputs	15
3.1.2.1	Reaction in the Event of a Fault	15
3.1.2.2	Line Control	16
3.2	Equipment, Scope of Delivery	17
3.2.1	IP Address and System ID (SRS)	17
3.3	Type Label	18
3.4	Assembly	19
3.4.1	LED Indicators	20
3.4.1.1	Operating Voltage LED	20
3.4.1.2	System LEDs	21
3.4.1.3	Communication LEDs	22
3.4.1.4	I/O LEDs	22
3.4.1.5	Fieldbus LEDs	22
3.4.2	Communication	23
3.4.2.1	Connections for Ethernet Communication	23
3.4.2.2	Network Ports Used for Ethernet Communication	23
3.4.2.3	Connections for Fieldbus Communication	24
3.4.3	Pin Assignments	24
3.4.3.1	Pin Assignment of D-sub Connectors FB1 and FB2	24
3.4.3.2	Pin Assignment of D-sub Connectors FB1 and FB2	25
3.4.3.3	Pin Assignment of D-sub Connectors FB1 and FB2	25
3.4.3.4	Pin Assignment of D-sub Connectors FB1 and FB2	25
3.4.3.5	Pin Assignment of D-sub Connectors FB1 and FB2	26
3.4.3.6	Pin Assignment of the D-sub Connector FB3	26

3.4.4	Reset Key	27
3.4.5	Hardware Clock	27
3.5	Product Data	28
3.5.1	Product Data F30 011 (F30 -20°)	29
3.6	Certified HIMatrix F30	30
4	Start-Up	31
4.1	Installation and Mounting	31
4.1.1	Connection of the Digital Inputs	31
4.1.1.1	Surges on Digital Inputs	32
4.1.2	Connecting the Digital Outputs	32
4.1.3	Mounting the F30 in Zone 2	33
4.2	Configuration	34
4.3	Configuration with SILworX	34
4.3.1	Parameters and Error Codes for the Inputs and Output	34
4.3.2	Digital Inputs for F30	35
4.3.2.1	Module Tab	35
4.3.2.2	DO 20: Channels Tab	36
4.3.3	Digital Outputs for F30	37
4.3.3.1	Module Tab	37
4.3.3.2	DO 8: Channels Tab	38
4.4	Configuring a Controller Using ELOP II Factory	39
4.4.1	Configuring the Inputs and Outputs	39
4.4.2	Signals and Error Codes for the Inputs and Output	39
4.4.3	Digital Inputs for F30	40
4.4.4	Digital Outputs for F30	42
5	Operation	43
5.1	Handling	43
5.2	Diagnosis	43
6	Maintenance	44
6.1	Faults	44
6.1.1	Operating System Version 6.42 and Beyond	44
6.1.2	Operating System Versions Prior to 6.42	44
6.2	Maintenance Measures	44
6.2.1	Loading the Operating System	44
6.2.2	Proof Test	44
7	Decommissioning	45
8	Transport	46
9	Disposal	47

Appendix 49
Glossary..... 49
Index of Figures 50
Index of Tables..... 51
Index..... 52

1 Introduction

This manual describes the technical characteristics of the device and its use. It also includes instructions on how to install, start up and replace it.

1.1 Structure and Use of this Manual

The content of this manual is part of the hardware description of the HIMatrix programmable electronic system.

This manual is organized in the following main chapters:

- Introduction
- Safety
- Product Description
- Start-Up
- Operation
- Maintenance
- Decommissioning
- Transport
- Disposal

This manual distinguishes between the following variants of the HIMatrix system:

Programming tool	Processor operating system	Communication operating system
SILworX	Version 7 and beyond	Version 12 and beyond
ELOP II Factory	Versions prior to 7	Versions prior to 12

Table 1: HIMatrix System Variants

The manual distinguishes among the different variants using:

- Separated chapters
- Tables differentiating among the versions, e.g., version 7 and beyond, or prior to version 7

i **Projects created with ELOP II Factory cannot be edited with SILworX, and vice versa!**

i This manual usually refers to compact controllers and remote I/Os as *devices*, and to the plug-in cards of a modular controller as *modules*.

Additionally, the following documents must be taken into account:

Name	Content	Document number
HIMatrix System Manual Compact Systems	Hardware description of the HIMatrix compact systems	HI 800 141 E
HIMatrix System Manual Modular System F60	Hardware description of the HIMatrix modular system	HI 800 191 E
Himatrix Safety Manual	Safety functions of the HIMatrix system	HI 800 023 E
HIMatrix Engineering Manual	Project planning description for HIMatrix systems	HI 800 101 E
HIMax Communication Manual	Description of the communication protocols, ComUserTask and their configuration in SILworX	HI 801 101 E
HIMatrix PROFIBUS DP Master/Slave Manual	Description of the PROFIBUS protocol and its configuration in ELOP II Factory	HI 800 009 E
HIMatrix Modbus Master/Slave Manual	Description of the Modbus protocol and its configuration in ELOP II Factory	HI 800 003 E
HIMatrix TCP S/R Manual	Description of the TCP S/R protocol and its configuration in ELOP II Factory	HI 800 117 E
HIMatrix ComUserTask (CUT) Manual	Description of the ComUserTask and its configuration in ELOP II Factory	HI 800 329 E
SILworX Online Help	Instructions on how to use SILworX	-
ELOP II Factory Online Help	Instructions on how to use ELOP II Factory, Ethernet IP protocol, INTERBUS protocol	-
First Steps SILworX	Introduction to SILworX using the HIMax system as an example	HI 801 103 E
First Steps ELOP II Factory	Introduction to ELOP II Factory	HI 800 006 E

Table 2: Additional Relevant Documents

The latest manuals can be downloaded from the HIMA website www.hima.com. The revision index on the footer can be used to compare the current version of existing manuals with the Internet edition.

1.2 Target Audience

This document addresses system planners, configuration engineers, programmers of automation devices and personnel authorized to implement, operate and maintain the modules and systems. Specialized knowledge of safety-related automation systems is required.

1.3 Formatting Conventions

To ensure improved readability and comprehensibility, the following fonts are used in this document:

Bold:	To highlight important parts Names of buttons, menu functions and tabs that can be clicked and used in the programming tool.
<i>Italics:</i>	For parameters and system variables
Courier	Literal user inputs
RUN	Operating state are designated by capitals
Chapter 1.2.3	Cross references are hyperlinks even though they are not particularly marked. When the cursor hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position.

Safety notes and operating tips are particularly marked.

1.3.1 Safety Notes

The safety notes are represented as described below. These notes must absolutely be observed to reduce the risk to a minimum. The content is structured as follows:

- Signal word: danger, warning, caution, notice
- Type and source of danger
- Consequences arising from the danger
- Danger prevention

SIGNAL WORD



Type and source of danger!
Consequences arising from the danger
Danger prevention

The signal words have the following meanings:

- Danger indicates hazardous situation which, if not avoided, will result in death or serious injury.
- Warning indicates hazardous situation which, if not avoided, could result in death or serious injury.
- Caution indicates hazardous situation which, if not avoided, could result in minor or modest injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

NOTE



Type and source of damage!
Damage prevention

1.3.2 Operating Tips

Additional information is structured as presented in the following example:

i The text corresponding to the additional information is located here.

Useful tips and tricks appear as follows:

TIP The tip text is located here.

2 Safety

The following safety information, notes and instructions must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

This product is operated with SELV or PELV. No imminent danger results from the product itself. The use in Ex-Zone is permitted if additional measures are taken.

2.1 Intended Use

HIMatrix components are designed for assembling safety-related controller systems.

When using the components in the HIMatrix system, comply with the following general requirements

2.1.1 Environmental Requirements

Requirement type	Range of values ¹⁾
Protection class	Protection class III in accordance with IEC/EN 61131-2
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
Housing	Standard: IP20
Supply voltage	24 VDC
¹⁾ The values specified in the technical data apply and are decisive for devices with extended environmental requirements.	

Table 3: Environmental Requirements

Exposing the HIMax system to environmental conditions other than those specified in this manual can cause the HIMatrix system to malfunction.

2.1.2 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace devices.

NOTE



Device damage due to electrostatic discharge!

- When performing the work, make sure that the workspace is free of static, and wear an ESD wrist strap.
- If not used, ensure that the device is protected from electrostatic discharge, e.g., by storing it in its packaging.

2.2 Residual Risk

No imminent danger results from a HIMatrix system itself.

Residual risk may result from:

- Faults in the engineering
- Faults in the user program
- Faults in the wiring

2.3 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.

2.4 Emergency Information

A HIMatrix system is a part of the safety equipment of a site. If a device or a module fails, the site adopts the safe state.

In case of emergency, no action that may prevent the HIMatrix systems from operating safely is permitted.

3 Product Description

The safety-related **F30** controller is a compact system located in a metal enclosure with 20 digital inputs and 8 digital outputs.

The controller is available in a model variant for SILworX and a model variant for ELOP II Factory, see Chapter 3.2. All variants are described in this manual.

The device is suitable for mounting in Ex-zone 2, see Chapter 4.1.3.

The device has been certified by the TÜV for safety-related applications up to SIL 3 (IEC 61508, IEC 61511 and IEC 62061), Cat. 4 (EN 954-1) and PL e (EN ISO 13849-1). Further safety standards, application standards and test standards are specified in the certificate available on the HIMA website.

3.1 Safety Function

The controller is equipped with safety-related digital inputs and outputs.

3.1.1 Safety-Related Digital Inputs

The controller is equipped with 20 digital inputs. The state (HIGH, LOW) of each input is signaled by an individual LED.

Mechanical contacts without own power supply or signal power source can be connected to the inputs.

Potential-free mechanical contacts without own power supply are fed via an internal short-circuit-proof 24 V power source (LS+). Each of them supply a group of 4 mechanical contacts. Figure 1 shows how the connection is performed.

With signal voltage sources, the corresponding ground must be connected to the input (L-), see Figure 1.




Figure 1: Connections to Safety-Related Digital Inputs

For the external wiring and the connection of sensors, apply the de-energized-to-trip principle. Thus, if a fault occurs, the input signals adopt a de-energized, safe state (low level).

If an external wire is not monitored, an open-circuit is considered as safe low level.

3.1.1.1 Reaction in the Event of a Fault

If the device detects a fault on a digital input, the user program processes a low level in accordance with the de-energized to trip principle.

The device activates the *FAULT* LED.

In addition to the channel signal value, the user program must also consider the corresponding error code.

The error code allows the user to configure additional fault reactions in the user program.

3.1.1.2 Line Control

Line control is used to detect short-circuits or open-circuits and can be configured for the F30 system, e.g., on EMERGENCY STOP inputs complying with Cat. 4 in accordance with EN 954-1.

To this end, connect the digital outputs DO 1 through DO 8 of the system to the digital inputs DI of the same system as follows:




Figure 2: Line Control

The controller pulses the digital outputs to detect the line short-circuits and open-circuits to the digital inputs. To do so, configure the *Value.[BOOL]* → system variable in SILworX and the *DO[0x].Value* system signal in ELOP II Factory. The variables for the pulsed outputs must begin with channel 1 and reside in direct sequence, one after the other.

If the following faults occur, the *FAULT* LED located on the front plate of the controller blinks, the inputs are set to low level and an (evaluable) error code is created:

- Cross-circuit between two parallel lines,
- Improper connections of two lines (e.g., DO 2 to DI 3),
- Earth fault of a line (with earthed ground only),
- Open-circuit or open contacts, i.e., also if one of the two EMERGENCY STOP switches previously mentioned the *FAULT* LED is being engaged.

For more information on how to configure line control in the user program, refer to the HIMatrix Engineering Manual (HI 800 101 E).

3.1.2 Safety-Related Digital Outputs

The controller is equipped with 8 digital outputs. The state (HIGH, LOW) of each output is signaled by an individual LED.

At the maximum ambient temperature, the outputs 1...3 and 5...7 can be loaded with 0.5 A each, and outputs 4 and 8 can be loaded with 1 A or with 2 A at an ambient temperature of up to 50 °C.

If an overload occurs, one or all outputs are switched off. If the overload is removed, the outputs are switched on again automatically, see Table 21.

The external wire of an output is not monitored, however, a detected short-circuit is signaled.




Figure 3: Connecting Actuators to Outputs

⚠ WARNING



For connecting a load to a 1-pole switching output, use the corresponding L- ground of the respective channel group (2-pole connection) to ensure that the internal protective circuit can function.

Inductive loads may be connected with no free-wheeling diode on the actuator. However, HIMA strongly recommends connecting a protective diode directly to the actuator.

3.1.2.1 Reaction in the Event of a Fault

If the device detects a faulty signal on a digital output, the affected module output is set to the safe (de-energized) state using the safety switches.

If a fault in the device occurs, all digital outputs are switched off.

In both cases, the device activates the *FAULT* LED.

The error code allows the user to configure additional fault reactions in the user program.

3.1.2.2 Line Control

The digital outputs can be used to detect the inputs for short-circuits and open-circuits, e.g., for an EMERGENCY STOP button complying with Cat. 4 in accordance with EN 954-1. To this end, the outputs are pulsed and connected to the safety-related digital inputs of the same device, see Chapter 3.1.1. In this case, the digital outputs assume the function of pulsed outputs.

WARNING



Pulsed outputs must not be used as safety-related outputs!

3.2 Equipment, Scope of Delivery

The available components and their part numbers are listed below:

Designation	Description	Part no.
F30 01	Compact controller with 20 digital inputs and 8 digital outputs. Operating temperature 0...+60 °C, for ELOP II Factory programming tool	98 2200415
F30 011 (-20 °C)	Compact controller with 20 digital inputs and 8 digital outputs. Operating temperature -20 °C...+60 °C, for ELOP II Factory programming tool	98 2200455
F30 01 SILworX	Compact controller with 20 digital inputs and 8 digital outputs. Operating temperature 0...+60 °C, for SILworX programming tool	98 2200472
F30 011 SILworX (-20 °C)	Compact controller with 20 digital inputs and 8 digital outputs. Operating temperature -20 °C...+60 °C, for SILworX programming tool	98 2200478

Table 4: Part Numbers

3.2.1 IP Address and System ID (SRS)

A transparent label is delivered with the device to allow one to note the IP address and the system ID (SRS for system rack slot) after a change.

IP ____ . ____ . ____ . ____ SRS ____ . ____ . ____

Default value for IP address: 192.168.0.99

Default value for SRS: 60000.0.0

The label must not be affixed such that the air vents on the cabinet are covered.

Refer to the First Steps manual of the programming tool for more information on how to modify the IP address and the system ID.

3.3 Type Label

The type plate contains the following details:

- Product name
- Bar code (1D or 2D code)
- Part no.
- Production year
- Hardware revision index (HW Rev.)
- Firmware revision index (FW Rev.)
- Operating voltage
- Mark of conformity




Figure 4: Sample Type Label

3.4 Assembly

This chapter describes the layout and function of the controller, and their connection for communication.





Figure 5: Front View



- 1** Digital Inputs
- 2** Safety-Related Processor System
- 3** Dual Port RAM
- 4** Communication System
- 5** Switch
- 6** Watchdog
- 7** Digital Outputs

Figure 6: Block Diagram

3.4.1 LED Indicators

The light-emitting diodes (LEDs) indicate the operating state of the controller. The LEDs are classified as follows:

- Operating Voltage LED
- System LEDs
- Communication LEDs
- I/O LEDs
- Fieldbus LEDs

3.4.1.1 Operating Voltage LED

LED	Color	Status	Description
24 VDC	Green	On	24 VDC operating voltage present
		Off	No operating voltage

Table 5: Operating Voltage LED

3.4.1.2 System LEDs

While the system is being booted, all LEDs are lit simultaneously.

LED	Color	Status	Description
RUN	Green	On	Device in RUN, normal operation A loaded user program is being executed (not with remote I/Os).
		Blinking	Device in STOP A new operating system is being loaded.
		Off	The device is not in the RUN state.
ERROR	Red	On	The device is in the ERROR STOP state. Internal fault detected by self-tests e.g., hardware fault, software error or cycle time overrun. The processor system can only be restarted with a command from the PADT (reboot).
		Blinking	If ERROR blinks and all others LEDs are lit simultaneously, the boot loader has detected an operating system fault in the flash memory and waits for a new operating system to be loaded.
		Off	No faults detected.
PROG	Yellow	On	A new configuration is being loaded into the device.
		Blinking	The device switches from INIT to STOP A new operating system is being loaded into the flash ROM.
		Off	No configuration or operating system is being loaded.
FORCE	Yellow	On	The device is in RUN, forcing was activated.
		Blinking	The device is in STOP, forcing has been prepared and is activated when the device is started.
		Off	Forcing is not activated. The FORCE LED of a remote I/O is not functioning. The FORCE LED of the associated controller serves to signal the forcing of a remote I/O.
FAULT	Yellow	On	The loaded configuration is defective. The new operating system is corrupted (after OS download).
		Blinking	Fault while loading a new operating system One or multiple I/O faults occurred.
		Off	None of the described faults occurred.
OSL	Yellow	Blinking	Operating system emergency loader active.
		Off	Operating system emergency loader inactive.
BL	Yellow	Blinking	OS and OLS binary defective or INIT_FAIL hardware fault.
		Off	Boot loader inactive

Table 6: System LEDs

3.4.1.3 Communication LEDs

All RJ-45 connectors are provided with a green and a yellow LED. The LEDs signal the following states:

LED	Status	Description
Green	On	Full duplex operation
	Blinking	Collision
	Off	Half duplex operation, no collision
Yellow	On	Connection available
	Blinking	Interface activity
	Off	No connection available

Table 7: Ethernet Indicators

3.4.1.4 I/O LEDs

LED	Color	Status	Description
DI 1...20	Yellow	On	The related channel is active (energized).
		Off	The related channel is inactive (de-energized).
DO 1...8	Yellow	On	The related channel is active (energized).
		Off	The related channel is inactive (de-energized).

Table 8: I/O LEDs

3.4.1.5 Fieldbus LEDs

LEDs FB1...3 are used to display the state of communication occurring via the serial interfaces. The function of the LED depends on the used protocol.

Refer to the corresponding Communication Manual for more details on the function.

3.4.2 Communication

The controller communicates with remote I/Os via **safeethernet**.

3.4.2.1 Connections for Ethernet Communication

Property	Description
Port	4 x RJ-45
Transfer standard	10/100/Base-T, half and full duplex
Auto negotiation	Yes
Auto crossover	Yes
Connection socket	RJ-45
IP address	Freely configurable ¹⁾
Subnet mask	Freely configurable ¹⁾
Supported protocols	<ul style="list-style-type: none"> ▪ Safety-related: safeethernet ▪ Non-safety-related: Ethernet/IP²⁾, OPC, programming and debugging tool (PADT), TCP-SR, SNTP, Modbus TCP
<p>¹⁾ The general rules for assigning IP address and subnet masks must be adhered to.</p> <p>²⁾ EtherNet/IP is not supported in SILworX..</p>	

Table 9: Ethernet Interfaces Properties

Two RJ-45 connectors with integrated LEDs are located on the top and on the bottom left-hand side of the enclosure. Refer to 3.4.1.3 for a description of the LEDs' function.

The connection parameters are read based on the MAC address (media access control address) defined during manufacturing.

The MAC address for the controller is specified on a label located above the two RJ-45 connectors (1 and 2).




Figure 7: Sample MAC Address Label

The HIMatrix F30 is equipped with an integrated switch for safety-related Ethernet communication (**safeethernet**). For further information on the integrated switch and **safeethernet**, refer to Chapter *Communication* of the System Manual for Compact Systems (HI 800 141 E).

3.4.2.2 Network Ports Used for Ethernet Communication

UDP ports	Use
8000	Programming and operation with the programming tool
8001	Configuration of the remote I/O using the PES (ELOP II Factory)
8004	Configuration of the remote I/O using the PES (SILworX)
6010	safeethernet and OPC
123	SNTP (time synchronization between PES and remote I/O, PES and external devices)
6005/ 6012	If TCS_DIRECT was not selected in the HH network
502	Modbus (can be modified by the user)
44818	EtherNet/IP session protocol for device identification
2222	EtherNet/IP Data Exchange

Table 10: Network Ports (UDP Ports) in Use

TCP ports	Use
502	Modbus (can be modified by the user)
xxx	TCP SR assigned by the user
44818	Ethernet/IP Explicit Messaging Services

Table 11: Network Ports (TCP Ports) in Use

3.4.2.3 Connections for Fieldbus Communication

The three 9-pole D-sub connectors are located on the front plate of the enclosure.

Designation	Fieldbus submodule	Protocols
FB 1 (with module)	PROFIBUS master PROFIBUS slave RS485 module RS232 module RS422 module INTERBUS Master	PROFIBUS DP master PROFIBUS DP slave RS485 for Modbus (master or slave) and ComUserTask RS232 for ComUserTask RS422 for ComUserTask INTERBUS ¹⁾ master
FB 2 (with module)	PROFIBUS master PROFIBUS slave RS485 module RS232 module RS422 module INTERBUS master	PROFIBUS DP master PROFIBUS DP slave RS485 for Modbus (master or slave) and ComUserTask RS232 for ComUserTask RS422 for ComUserTask INTERBUS ¹⁾ master
FB 3	RS485	RS485 for Modbus (master or slave) and ComUserTask
¹⁾ INTERBUS is not supported in SILworX.		

Table 12: Connections for Fieldbus Communication

The fieldbus submodules for communication via FB1 and FB2 are optional and are must be mounted by the manufacturer.

3.4.3 Pin Assignments

The following tables describe the Pin assignments of the fieldbus connectors.

3.4.3.1 Pin Assignment of D-sub Connectors FB1 and FB2

with fieldbus submodule for PROFIBUS DP master or slave

Connection	Signal	Function
1	---	---
2	---	---
3	RxD/TxD-A	Receive/send data A
4	RTS	Control signal
5	DGND	Data ground
6	VP	5 V, plus pole supply voltage
7	---	---
8	RxD/TxD-B	Receive/send data B
9	---	---

Table 13: Pin Assignment of D-sub Connectors FB1 and FB2 for PROFIBUS DP

3.4.3.2 Pin Assignment of D-sub Connectors FB1 and FB2 with RS485 fieldbus submodule for Modbus master or slave and ComUserTask

Connection	Signal	Function
1	---	---
2	RP	5 V decoupled with diodes
3	RxD/TxD-A	Receive/send data A
4	CNTR-A	Control signal A
5	DGND	Data ground
6	VP	5 V, plus pole supply voltage
7	---	---
8	RxD/TxD-B	Receive/send data B
9	CNTR-B	Control signal B

Table 14: Pin Assignment of the D-sub Connectors FB1 and FB2 for RS485

3.4.3.3 Pin Assignment of D-sub Connectors FB1 and FB2 with RS232 fieldbus submodule for ComUserTask

Connection	Signal	Function
1	---	---
2	TxD	Send data
3	RxD	Receive data
4	---	---
5	DGND	Data ground
6	---	---
7	RTS	Request to send
8	---	---
9	---	---

Table 15: Pin Assignment of the D-sub Connectors FB1 and FB2 for RS232

3.4.3.4 Pin Assignment of D-sub Connectors FB1 and FB2 with RS422 fieldbus submodule for ComUserTask

Connection	Signal	Function
1	---	---
2	RP	+5 V decoupled with diodes
3	RxA	Receive data A
4	TxA	Send data A
5	DGND	Data ground
6	VP	+5 V supply voltage
7	---	---
8	RxB	Receive data B
9	TxB	Send data B

Table 16: Pin Assignment of the D-sub Connectors FB1 and FB2 for RS422

3.4.3.5 Pin Assignment of D-sub Connectors FB1 and FB2 with fieldbus submodule for INTERBUS

Connection	Signal	Function
1	DO	Positive data output
2	DI	Positive data input
3	COM	Common 0 V line
4	---	---
5	---	---
6	DO-	Negative data input
7	DI-	Negative data output
8	---	---
9	---	---

Table 17: Pin Assignment of the D-sub Connectors FB1 and FB2 for INTERBUS

3.4.3.6 Pin Assignment of the D-sub Connector FB3 Modbus master or slave

Connection	Signal	Function
1	---	---
2	---	---
3	RxD/TxD-A	Receive/send data A
4	CNTR-A	Control signal A
5	DGND	Data ground
6	VP	5 V, plus pole supply voltage
7	---	---
8	RxD/TxD-B	Receive/send data B
9	CNTR-B	Control signal B

Table 18: Pin Assignment of D-sub Connector FB3 for Modbus

3.4.4 Reset Key

The controller is equipped with a reset key. The key is only required if the user name or password for administrator access is not known. If only the IP address set for the controller does not match the PADT (PC), the connection can be established with a `Route add` entry on the PC.

The key can be accessed through a small round hole located approximately 5 cm from the upper left-hand side of the enclosure. The key is engaged using a suitable pin made of insulating material to avoid short-circuits within the controller.

The reset is only effective if the controller is rebooted (switched off and on) while the key is simultaneously engaged for at least 20 seconds. Engaging the key during operation has no effect.

WARNING



Caution! Fieldbus communication may be disturbed!

Prior to switching on the controller with the reset key engaged, all device fieldbus connectors must be unplugged to ensure that the fieldbus communication among other stations is not disturbed.

The fieldbus plugs may only be plugged in again when the controller is in the RUN or STOP state.

Properties and behavior of the controller after a reboot with engaged reset key:

- Connection parameters (IP address and system ID) are set to the default values.
- All accounts are deactivated except for the default account administrator with empty password.
- With COM operating system version 10.42 and beyond, loading a user program or operating system with default connection parameters is inhibited!
The loading procedure is only allowed after the connection parameters and the account have been configured on the controller and the controller has been rebooted.

After a new reboot without the reset key engaged, the connection parameters (IP address and system ID) and accounts become effective.

- Those configured by the user.
- Those valid prior to rebooting with the reset key engaged, if no changes were performed.

3.4.5 Hardware Clock

In case of loss of operating voltage, the power provided by an integrated gold capacitor is sufficient to buffer the hardware clock for approximately one week.

3.5 Product Data

General	
User memory	Versions prior to 6.46 max. 500 kB user program max. 500 kB user data Version 6.100 max. 2047 kB user program max. 2047 kB user data Version 7 max. 1023 kB user program max. 1023 kB user data
Response time	≥ 20 ms
Interfaces: Ethernet PROFIBUS DP master/slave Modbus master/slave INTERBUS master RS485 (Modbus master/slave)	4 x RJ-45, 10/100BaseT (with 100 Mbit/s) with integrated switch 9-pole D-sub (FB2, FB2) 9-pole D-sub (FB3)
Operating voltage	24 VDC, -15 %...+20 %, $w_{ss} \leq 15 \%$, from a power supply unit with safe insulation, in accordance with IEC 61131-2.
Current input	max. 8 A (with maximum load) Idle: 0.5 A
Fuse (external)	10 A time-lag (T)
Buffer for date/time	Gold capacitor
Operating temperature	0 °C...+60 °C
Storage temperature	-40 °C...+85 °C
Type of protection	IP20
Max. dimensions (without plug)	Width: 257 mm (with enclosure screws) Height: 114 mm (with fixing bolt) Depth: 66 mm (with earthing screw)
Weight	approx. 1.2 kg

Table 19: Product Data

Digital inputs	
Number of inputs	20 (non-galvanically isolated)
High level: Voltage	15...30 VDC
Current input	≥ 2 mA at 15 V
Low level: Voltage	max. 5 VDC
Current input	max. 1.5 mA (1 mA at 5 V)
Switching point	typ. 7.5 V
Supply	5 x 20 V / 100 mA (at 24 V), short-circuit-proof

Table 20: Specifications for the Digital Inputs

Digital outputs	
Number of outputs	8 (non-galvanically isolated)
Output voltage	$\geq L+$ minus 2 V
Output current	Channels 1...3 and 5...7: 0.5 A at 60 °C Channels 4 and 8: 1 A at 60 °C, 2 A at 50 °C)
Minimum load	2 mA for each channel
Internal voltage drop	max. 2 V at 2 A
Leakage current (with low level)	max. 1 mA at 2 V
Behavior with overload	The affected output is switched off and cyclically switched on again
Total output current	max. 7 mA Upon overload, all outputs are switched off and cyclically switched on again

Table 21: Specifications for the Digital Outputs

3.5.1 Product Data F30 011 (F30 -20°)

The F30 011 model variant is intended for use at the extended temperature range of -20°C...+60 °C. The electronic components are coated with a protective lacquer.

General	
Operating temperature	-20...+60 °C
Weight	approx. 1.2 kg

Table 22: Product Data F30 011

3.6 Certified HIMatrix F30

HIMatrix F30	
CE	EMC, ATEX Zone 2
TÜV	IEC 61508 1-7:2000 up to SIL 3 IEC 61511:2004 EN 954-1:1996 up to Cat. 4
TÜV ATEX	94/9/EG EN 1127-1 EN 61508
Lloyd's Register	Shipping certification ENV1, ENV2 and ENV3. Test Specification Number: 1 - 2002
UL Underwriters Laboratories Inc.	ANSI/UL 508, NFPA 70 – Industrial Control Equipment CSA C22.2 No.142 UL 1998 Software Programmable Components NFPA 79 Electrical Standard for Industrial Machinery IEC 61508
FM Approvals	Class I, DIV 2, Groups A, B, C and D Class 3600, 1998 Class 3611, 1999 Class 3810, 1989 Including Supplement #1, 1995 CSA C22.2 No 142 CSA C22.2 No 213
PROFIBUS Nutzerorganisation (PNO)	Test Specification for PROFIBUS DP Slave, Version 3.0 November 2005

Table 23: Certificates

4 Start-Up

To start up the controller, it must be mounted, connected and configured in the programming tool.

4.1 Installation and Mounting

The controller is mounted on a 35 mm DIN rail such as described in the HIMatrix Manual for Compact Systems.

4.1.1 Connection of the Digital Inputs

Use the following terminals to connect the digital inputs:

Terminal	Designation	Function
13	LS+	Sensor supply of the inputs 1...4
14	1	Digital input 1
15	2	Digital input 2
16	3	Digital input 3
17	4	Digital input 4
18	L-	Ground
Terminal	Designation	Function
19	LS+	Sensor supply of the inputs 5...8
20	5	Digital input 5
21	6	Digital input 6
22	7	Digital input 7
23	8	Digital input 8
24	L-	Ground
Terminal	Designation	Function
25	LS+	Sensor supply of the inputs 9...12
26	9	Digital input 9
27	10	Digital input 10
28	11	Digital input 11
29	12	Digital input 12
30	L-	Ground
Terminal	Designation	Function
31	LS+	Sensor supply of the inputs 13...16
32	13	Digital input 13
33	14	Digital input 14
34	15	Digital input 15
35	16	Digital input 16
36	L-	Ground
Terminal	Designation	Function
37	LS+	Sensor supply of the inputs 17...20
38	17	Digital input 17
39	18	Digital input 18
40	19	Digital input 19
41	20	Digital input 20
42	L-	Ground

Table 24: Terminal Assignment for the Digital Inputs

4.1.1.1 Surges on Digital Inputs

Due to the short cycle time of the HIMatrix systems, a surge pulse as described in EN 61000-4-5 can be read in to the digital inputs as a short-term high level.

The following measures ensure proper operation in environments where surges may occur:

1. Install shielded input wires
2. Activate noise blanking: a signal must be present for at least two cycles before it is evaluated.

i

Activating noise blanking increases the response time of the HIMatrix system!

i

The measures specified above are not necessary if the plant design precludes surges from occurring within the system.

In particular, the design must include protective measures with respect to overvoltage, lightning, earth grounding and plant wiring in accordance with the relevant standards and the instructions specified in the System Manual (HI 800 141 E or HI 800 191 E).

4.1.2 Connecting the Digital Outputs

Use the following terminals to connect the digital outputs:

Terminal	Designation	Function
1	LS+	Ground channel group
2	1	Digital output 1
3	2	Digital output 2
4	3	Digital output 3
5	4	Digital output 4 (for increased load)
6	L-	Ground channel group
Terminal	Designation	Function
7	LS+	Ground channel group
8	5	Digital output 5
9	6	Digital output 6
10	7	Digital output 7
11	8	Digital output 8 (for increased load)
12	L-	Ground channel group

Table 25: Terminal Assignment for the Digital Outputs

4.1.3 Mounting the F30 in Zone 2

(EC Directive 94/9/EC, ATEX)

The controller is suitable for mounting in zone 2. Refer to the corresponding declaration of conformity available on the HIMA website.

When mounting the device, observe the special conditions specified in the following section.

Special Conditions X

1. Mount the HIMatrix controller F30 in an enclosure that meets the EN 60079-15 requirements and achieves a type of protection of at least IP54, in accordance with EN 60529. Provide the enclosure with the following label:

Work is only permitted in the de-energized state

Exception:

If a potentially explosive atmosphere has been precluded, work can be also performed when the device is under voltage:

2. The enclosure in use must be able to safely dissipate the generated heat. Depending on the output load and supply voltage, the HIMatrix F30 has a power dissipation ranging between 12 W and 33 W.
3. Protect the HIMatrix F30 with a 10 A time-lag fuse.
The F20 must be supplied with 24 VDC from a power supply unit with safe isolation. Use power supply units of type PELV or SELV only.
4. Applicable standards:

VDE 0170/0171 Part 16,	DIN EN 60079-15: 2004-5
VDE 0165 Part 1,	DIN EN 60079-14: 1998-08

Pay particular attention to the following sections:

DIN EN 60079-15:

Chapter 5	Design
Chapter 6	Terminals and cabling
Chapter 7	Air and creeping distances
Chapter 14	Connectors

DIN EN 60079-14:

Chapter 5.2.3	Equipment for use in zone 2
Chapter 9.3	Cabling for zones 1 and 2
Chapter 12.2	Equipment for zones 1 and 2

The module is additionally equipped with the label represented below:




Figure 8: Label for Ex Conditions

4.2 Configuration

The controller can be configured using a programming tool, SILworX or ELOP II Factory. Which programming tool should be used, depends on the revision status of the operating system (firmware):

- ELOP II Factory is required for operating system versions prior to 7.
- SILworX is required for operating system version 7 and beyond.

i

ELOP II Factory is required to load a new operating system (version 7 or beyond) into a controller with a CPU operating system version prior to 7. SILworX is then required once the loading procedure is completed.

4.3 Configuration with SILworX

In the Hardware Editor, the controller is represented like a base plate equipped with the following modules:

- Processor module (CPU)
- Communication module (COM)
- Input module (DI 20)
- Output module (DO 8)

Double-click the module to open the Detail View with the corresponding tabs. The tabs are used to assign the global variables configured in the user program to the system variables.

4.3.1 Parameters and Error Codes for the Inputs and Output

The following tables specify the system parameters that can be read and set for the inputs and outputs, including the corresponding error codes.

In the user program, the error codes can be read using the variables assigned within the logic.

The error codes can also be displayed in SILworX.

4.3.2 Digital Inputs for F30

The following tables present the statuses and parameters for the input module (DI 20) in the same order as given in the Hardware Editor.

4.3.2.1 Module Tab

The **Module** tab contains the following system parameters.

System parameter	Data type	R/W	Description																
DI No. of Pulse Channel	USINT	W	Number of pulsed outputs (supply outputs)																
			<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No pulsed output planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>1</td> <td>Pulsed output 1 planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>2</td> <td>Pulsed outputs 1 and 2 planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>8</td> <td>Pulsed outputs 1...8 planned for LS/LB¹⁾ detection</td> </tr> </tbody> </table>	Coding	Description	0	No pulsed output planned for LS/LB ¹⁾ detection	1	Pulsed output 1 planned for LS/LB ¹⁾ detection	2	Pulsed outputs 1 and 2 planned for LS/LB ¹⁾ detection	8	Pulsed outputs 1...8 planned for LS/LB ¹⁾ detection				
			Coding	Description															
			0	No pulsed output planned for LS/LB ¹⁾ detection															
			1	Pulsed output 1 planned for LS/LB ¹⁾ detection															
			2	Pulsed outputs 1 and 2 planned for LS/LB ¹⁾ detection															
...	...																		
8	Pulsed outputs 1...8 planned for LS/LB ¹⁾ detection																		
Pulsed outputs must not be used as safety-related outputs!																			
DI Pulse Delay (10E-6s)	UINT	W	Waiting time for line control (detection of short-circuits or cross-circuits)																
DI Pulse Slot	UDINT	W	Pulse module slot (LS/LB ¹⁾ detection, set the value to 3																
DI.Error Code	WORD	R	Error codes for all digital inputs																
			<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Fault within the digital inputs</td> </tr> <tr> <td>0x0002</td> <td>FTT test of test pattern faulty</td> </tr> </tbody> </table>	Coding	Description	0x0001	Fault within the digital inputs	0x0002	FTT test of test pattern faulty										
			Coding	Description															
0x0001	Fault within the digital inputs																		
0x0002	FTT test of test pattern faulty																		
Module Error Code	WORD	R	Module error code																
			<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0000</td> <td>I/O processing, if required with errors see other error codes</td> </tr> <tr> <td>0x0001</td> <td>No I/O processing (CPU not in RUN)</td> </tr> <tr> <td>0x0002</td> <td>No I/O processing during the booting test</td> </tr> <tr> <td>0x0004</td> <td>Manufacturer interface operating</td> </tr> <tr> <td>0x0010</td> <td>No I/O processing: incorrect configuration</td> </tr> <tr> <td>0x0020</td> <td>No I/O processing: fault rate exceeded</td> </tr> <tr> <td>0x0040/ 0x0080</td> <td>No I/O processing: configured module not plugged in</td> </tr> </tbody> </table>	Coding	Description	0x0000	I/O processing, if required with errors see other error codes	0x0001	No I/O processing (CPU not in RUN)	0x0002	No I/O processing during the booting test	0x0004	Manufacturer interface operating	0x0010	No I/O processing: incorrect configuration	0x0020	No I/O processing: fault rate exceeded	0x0040/ 0x0080	No I/O processing: configured module not plugged in
			Coding	Description															
			0x0000	I/O processing, if required with errors see other error codes															
			0x0001	No I/O processing (CPU not in RUN)															
			0x0002	No I/O processing during the booting test															
			0x0004	Manufacturer interface operating															
			0x0010	No I/O processing: incorrect configuration															
0x0020	No I/O processing: fault rate exceeded																		
0x0040/ 0x0080	No I/O processing: configured module not plugged in																		
Module.SRS	[UDINT]	R	Slot number (System Rack Slot)																
Module.Type	[UINT]	R	Type of module, target value: 0x00A5 [165 _{dec}]																

¹⁾ LS/LB (LS = short-circuit, LB = open-circuit)

Table 26: SILworX - System Parameters for the Digital Inputs, **Module** Tab

4.3.2.2 DO 20: Channels Tab

The DI 20: Channels tab contains the following system parameters.

System parameter	Data type	R/W	Description												
Channel no.	---	R	Channel number, defined by default												
-> Error Code [BYTE]	BYTE	R	Error codes for the digital input channels <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital input module</td> </tr> <tr> <td>0x10</td> <td>Short-circuit of the channel</td> </tr> <tr> <td>0x80</td> <td> Open-circuit between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage </td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital input module	0x10	Short-circuit of the channel	0x80	Open-circuit between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 				
Coding	Description														
0x01	Fault in the digital input module														
0x10	Short-circuit of the channel														
0x80	Open-circuit between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 														
-> Value [BOOL]	BOOL	R	Input values for the digital input channels 0 = input de-energized 1 = input energized												
Pulse channel [USINT] ->	USINT	W	Source channel for pulsed supply <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Input channel</td> </tr> <tr> <td>1</td> <td>Pulse of the 1st DO channel</td> </tr> <tr> <td>2</td> <td>Pulse of the 2nd DO channel</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>8</td> <td>Pulse of the 8th DO channel</td> </tr> </tbody> </table>	Coding	Description	0	Input channel	1	Pulse of the 1st DO channel	2	Pulse of the 2nd DO channel	8	Pulse of the 8th DO channel
Coding	Description														
0	Input channel														
1	Pulse of the 1st DO channel														
2	Pulse of the 2nd DO channel														
...	...														
8	Pulse of the 8th DO channel														

Table 27: SILworX - System Parameters for the Digital Inputs, DI 20: Channels Tab

4.3.3 Digital Outputs for F30

The following tables present the statuses and parameters for the output module (DO 8) in the same order as given in the Hardware Editor.

4.3.3.1 **Module Tab**

The **Module** tab contains the following system parameters.

System parameter	Data type	R/W	Description																								
DO.Error Code	WORD	R	Error codes for all digital outputs																								
			<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Fault within the digital outputs</td> </tr> <tr> <td>0x0002</td> <td>MOT test of safety shutdown returns a fault</td> </tr> <tr> <td>0x0004</td> <td>MOT test of auxiliary voltage returns a fault</td> </tr> <tr> <td>0x0008</td> <td>FTT test of test pattern faulty</td> </tr> <tr> <td>0x0010</td> <td>MOT test of output switch test pattern faulty</td> </tr> <tr> <td>0x0020</td> <td>MOT test of output switch test pattern (shutdown test of the outputs) faulty</td> </tr> <tr> <td>0x0040</td> <td>MOT test active shutdown via WD faulty</td> </tr> <tr> <td>0x0200</td> <td>All outputs are switched off, total current exceeded</td> </tr> <tr> <td>0x0400</td> <td>FTT test: 1st temperature threshold exceeded</td> </tr> <tr> <td>0x0800</td> <td>FTT test: 2nd temperature threshold exceeded</td> </tr> <tr> <td>0x1000</td> <td>FTT test: Monitoring of auxiliary voltage 1: Low voltage</td> </tr> </tbody> </table>	Coding	Description	0x0001	Fault within the digital outputs	0x0002	MOT test of safety shutdown returns a fault	0x0004	MOT test of auxiliary voltage returns a fault	0x0008	FTT test of test pattern faulty	0x0010	MOT test of output switch test pattern faulty	0x0020	MOT test of output switch test pattern (shutdown test of the outputs) faulty	0x0040	MOT test active shutdown via WD faulty	0x0200	All outputs are switched off, total current exceeded	0x0400	FTT test: 1st temperature threshold exceeded	0x0800	FTT test: 2nd temperature threshold exceeded	0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage
			Coding	Description																							
			0x0001	Fault within the digital outputs																							
			0x0002	MOT test of safety shutdown returns a fault																							
			0x0004	MOT test of auxiliary voltage returns a fault																							
			0x0008	FTT test of test pattern faulty																							
			0x0010	MOT test of output switch test pattern faulty																							
			0x0020	MOT test of output switch test pattern (shutdown test of the outputs) faulty																							
			0x0040	MOT test active shutdown via WD faulty																							
			0x0200	All outputs are switched off, total current exceeded																							
			0x0400	FTT test: 1st temperature threshold exceeded																							
0x0800	FTT test: 2nd temperature threshold exceeded																										
0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage																										
Module Error Code	WORD	R	Module error code																								
			<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0000</td> <td>I/O processing, if required with errors, see other error codes</td> </tr> <tr> <td>0x0001</td> <td>No I/O processing (CPU not in RUN)</td> </tr> <tr> <td>0x0002</td> <td>No I/O processing during the booting test</td> </tr> <tr> <td>0x0004</td> <td>Manufacturer interface operating</td> </tr> <tr> <td>0x0010</td> <td>No I/O processing: incorrect configuration</td> </tr> <tr> <td>0x0020</td> <td>No I/O processing: fault rate exceeded</td> </tr> <tr> <td>0x0040/ 0x0080</td> <td>No I/O processing: configured module not plugged in</td> </tr> </tbody> </table>	Coding	Description	0x0000	I/O processing, if required with errors, see other error codes	0x0001	No I/O processing (CPU not in RUN)	0x0002	No I/O processing during the booting test	0x0004	Manufacturer interface operating	0x0010	No I/O processing: incorrect configuration	0x0020	No I/O processing: fault rate exceeded	0x0040/ 0x0080	No I/O processing: configured module not plugged in								
			Coding	Description																							
			0x0000	I/O processing, if required with errors, see other error codes																							
			0x0001	No I/O processing (CPU not in RUN)																							
			0x0002	No I/O processing during the booting test																							
			0x0004	Manufacturer interface operating																							
			0x0010	No I/O processing: incorrect configuration																							
0x0020	No I/O processing: fault rate exceeded																										
0x0040/ 0x0080	No I/O processing: configured module not plugged in																										
Module SRS	UDINT	R	Slot number (System Rack Slot)																								
Module Type	UINT	R	Type of module, target value: 0x00B4 [180 _{dec}]																								

Table 28: SILworX - System Parameters for the Digital Outputs, **Module** Tab

4.3.3.2 DO 8: Channels Tab

The **DO 8: Channels** tab contains the following system parameters.

System parameter	Data type	R/W	Description										
Channel no.	---	R	Channel number, defined by default										
-> Error Code [BYTE]	BYTE	R	Error codes for the digital output channels <table border="1" data-bbox="657 389 1382 607"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital output module</td> </tr> <tr> <td>0x02</td> <td>Channel shutdown due to overload</td> </tr> <tr> <td>0x04</td> <td>Error while reading back the digital outputs</td> </tr> <tr> <td>0x08</td> <td>Error while reading back the status of the digital outputs</td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital output module	0x02	Channel shutdown due to overload	0x04	Error while reading back the digital outputs	0x08	Error while reading back the status of the digital outputs
Coding	Description												
0x01	Fault in the digital output module												
0x02	Channel shutdown due to overload												
0x04	Error while reading back the digital outputs												
0x08	Error while reading back the status of the digital outputs												
Value [BOOL] ->	BOOL	W	Output value for DO channels: 1 = output energized 0 = output de-energized Pulsed outputs must not be used as safety-related outputs!										

Table 29: SILworX - System Parameters for the Digital Outputs, **DO 8: Channels** Tab

4.4 Configuring a Controller Using ELOP II Factory

4.4.1 Configuring the Inputs and Outputs

The signals previously defined in the Signal Editor (Hardware Management) are assigned to the individual channels (inputs and outputs) using ELOP II Factory. Refer to the System Manual for Compact Systems or the online help for more details.

The following chapter describes the system signals used for assigning signals in the controller.

4.4.2 Signals and Error Codes for the Inputs and Output

The following tables specify the system signals that can be read and set for the inputs and outputs, including the corresponding error codes.

In the user program, the error codes can be read using the signals assigned within the logic.

The error codes can also be displayed in ELOP II Factory.

4.4.3 Digital Inputs for F30

System Signal	R/W	Description																
Mod.SRS [UDINT]	R	Slot number (System Rack Slot)																
Mod. Type [UINT]	R	Type of module, target value: 0x00A5 [165 _{dec}]																
Mod. Error Code [WORD]	R	Module error code <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0000</td> <td>I/O processing, if required with errors see other error codes</td> </tr> <tr> <td>0x0001</td> <td>No I/O processing (CPU not in RUN)</td> </tr> <tr> <td>0x0002</td> <td>No I/O processing during the booting test</td> </tr> <tr> <td>0x0004</td> <td>Manufacturer interface operating</td> </tr> <tr> <td>0x0010</td> <td>No I/O processing: incorrect configuration</td> </tr> <tr> <td>0x0020</td> <td>No I/O processing: fault rate exceeded</td> </tr> <tr> <td>0x0040/ 0x0080</td> <td>No I/O processing: configured module not plugged in</td> </tr> </tbody> </table>	Coding	Description	0x0000	I/O processing, if required with errors see other error codes	0x0001	No I/O processing (CPU not in RUN)	0x0002	No I/O processing during the booting test	0x0004	Manufacturer interface operating	0x0010	No I/O processing: incorrect configuration	0x0020	No I/O processing: fault rate exceeded	0x0040/ 0x0080	No I/O processing: configured module not plugged in
Coding	Description																	
0x0000	I/O processing, if required with errors see other error codes																	
0x0001	No I/O processing (CPU not in RUN)																	
0x0002	No I/O processing during the booting test																	
0x0004	Manufacturer interface operating																	
0x0010	No I/O processing: incorrect configuration																	
0x0020	No I/O processing: fault rate exceeded																	
0x0040/ 0x0080	No I/O processing: configured module not plugged in																	
DI.Error code [WORD]	R	Error codes for all digital inputs <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Fault within the digital inputs</td> </tr> <tr> <td>0x0002</td> <td>FTT test of test pattern faulty</td> </tr> </tbody> </table>	Coding	Description	0x0001	Fault within the digital inputs	0x0002	FTT test of test pattern faulty										
Coding	Description																	
0x0001	Fault within the digital inputs																	
0x0002	FTT test of test pattern faulty																	
DI[xx].Error code [BYTE]	R	Error codes for the digital input channels <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital input module</td> </tr> <tr> <td>0x10</td> <td>Short-circuit of the channel</td> </tr> <tr> <td>0x80</td> <td>Open-circuit between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage </td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital input module	0x10	Short-circuit of the channel	0x80	Open-circuit between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 								
Coding	Description																	
0x01	Fault in the digital input module																	
0x10	Short-circuit of the channel																	
0x80	Open-circuit between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 																	
DI[xx].Value [BOOL]	R	Input values for the digital input channels 0 = input de-energized 1 = input energized																
DI No. of Pulse Channel [USINT]	W	Number of pulsed outputs (supply outputs) <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No pulsed output planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>1</td> <td>Pulsed output 1 planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>2</td> <td>Pulsed outputs 1 and 2 planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>8</td> <td>Pulsed outputs 1...8 planned for LS/LB¹⁾ detection</td> </tr> </tbody> </table> <p>Pulsed outputs must not be used as safety-related outputs!</p>	Coding	Description	0	No pulsed output planned for LS/LB ¹⁾ detection	1	Pulsed output 1 planned for LS/LB ¹⁾ detection	2	Pulsed outputs 1 and 2 planned for LS/LB ¹⁾ detection	8	Pulsed outputs 1...8 planned for LS/LB ¹⁾ detection				
Coding	Description																	
0	No pulsed output planned for LS/LB ¹⁾ detection																	
1	Pulsed output 1 planned for LS/LB ¹⁾ detection																	
2	Pulsed outputs 1 and 2 planned for LS/LB ¹⁾ detection																	
...	...																	
8	Pulsed outputs 1...8 planned for LS/LB ¹⁾ detection																	
DI Pulse Slot [UDINT]	W	Pulse module slot (LS/LB ¹⁾ detection), set the value to 2																
DI[xx].Pulse Channel [USINT]	W	Source channel for pulsed supply <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Input channel</td> </tr> <tr> <td>1</td> <td>Pulse of the 1st DO channel</td> </tr> <tr> <td>2</td> <td>Pulse of the 2nd DO channel</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>8</td> <td>Pulse of the 8th DO channel</td> </tr> </tbody> </table>	Coding	Description	0	Input channel	1	Pulse of the 1st DO channel	2	Pulse of the 2nd DO channel	8	Pulse of the 8th DO channel				
Coding	Description																	
0	Input channel																	
1	Pulse of the 1st DO channel																	
2	Pulse of the 2nd DO channel																	
...	...																	
8	Pulse of the 8th DO channel																	

System Signal	R/W	Description
DI pulse delay (10E-6s) [UINT]	W	Waiting time for line control (detection of short-circuits or cross-circuits)
¹⁾ LS/LB (LS = short-circuit, LB = open-circuit)		

Table 30: ELOP II Factory - Digital Input System Signals

4.4.4 Digital Outputs for F30

System Signal	R/W	Description																								
Mod.SRS [UDINT]	R	Slot number (System Rack Slot)																								
Mod. Type [UINT]	R	Type of module, target value: 0x00B4 [180 _{dec}]																								
Mod. Error Code [WORD]	R	Module error code																								
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0000</td> <td>I/O processing, if required with errors, see other error codes</td> </tr> <tr> <td>0x0001</td> <td>No I/O processing (CPU not in RUN)</td> </tr> <tr> <td>0x0002</td> <td>No I/O processing during the booting test</td> </tr> <tr> <td>0x0004</td> <td>Manufacturer interface operating</td> </tr> <tr> <td>0x0010</td> <td>No I/O processing: incorrect configuration</td> </tr> <tr> <td>0x0020</td> <td>No I/O processing: fault rate exceeded</td> </tr> <tr> <td>0x0040/ 0x0080</td> <td>No I/O processing: configured module not plugged in</td> </tr> </tbody> </table>	Coding	Description	0x0000	I/O processing, if required with errors, see other error codes	0x0001	No I/O processing (CPU not in RUN)	0x0002	No I/O processing during the booting test	0x0004	Manufacturer interface operating	0x0010	No I/O processing: incorrect configuration	0x0020	No I/O processing: fault rate exceeded	0x0040/ 0x0080	No I/O processing: configured module not plugged in								
		Coding	Description																							
		0x0000	I/O processing, if required with errors, see other error codes																							
		0x0001	No I/O processing (CPU not in RUN)																							
		0x0002	No I/O processing during the booting test																							
		0x0004	Manufacturer interface operating																							
		0x0010	No I/O processing: incorrect configuration																							
0x0020	No I/O processing: fault rate exceeded																									
0x0040/ 0x0080	No I/O processing: configured module not plugged in																									
DO.Error code [WORD]	R	Error codes for all digital outputs																								
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Fault within the digital outputs</td> </tr> <tr> <td>0x0002</td> <td>MOT test of safety shutdown provides a fault</td> </tr> <tr> <td>0x0004</td> <td>MOT test of auxiliary voltage provides a fault</td> </tr> <tr> <td>0x0008</td> <td>FTT test of test pattern faulty</td> </tr> <tr> <td>0x0010</td> <td>MOT test of output switch test pattern faulty</td> </tr> <tr> <td>0x0020</td> <td>MOT test of output switch test pattern (shutdown test of the outputs) faulty</td> </tr> <tr> <td>0x0040</td> <td>MOT test active shutdown via WD faulty</td> </tr> <tr> <td>0x0200</td> <td>All outputs are switched off, total current exceeded</td> </tr> <tr> <td>0x0400</td> <td>FTT test: 1st temperature threshold exceeded</td> </tr> <tr> <td>0x0800</td> <td>FTT test: 2nd temperature threshold exceeded</td> </tr> <tr> <td>0x1000</td> <td>FTT test: Monitoring of auxiliary voltage 1: Low voltage</td> </tr> </tbody> </table>	Coding	Description	0x0001	Fault within the digital outputs	0x0002	MOT test of safety shutdown provides a fault	0x0004	MOT test of auxiliary voltage provides a fault	0x0008	FTT test of test pattern faulty	0x0010	MOT test of output switch test pattern faulty	0x0020	MOT test of output switch test pattern (shutdown test of the outputs) faulty	0x0040	MOT test active shutdown via WD faulty	0x0200	All outputs are switched off, total current exceeded	0x0400	FTT test: 1st temperature threshold exceeded	0x0800	FTT test: 2nd temperature threshold exceeded	0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage
		Coding	Description																							
		0x0001	Fault within the digital outputs																							
		0x0002	MOT test of safety shutdown provides a fault																							
		0x0004	MOT test of auxiliary voltage provides a fault																							
		0x0008	FTT test of test pattern faulty																							
		0x0010	MOT test of output switch test pattern faulty																							
		0x0020	MOT test of output switch test pattern (shutdown test of the outputs) faulty																							
		0x0040	MOT test active shutdown via WD faulty																							
		0x0200	All outputs are switched off, total current exceeded																							
		0x0400	FTT test: 1st temperature threshold exceeded																							
0x0800	FTT test: 2nd temperature threshold exceeded																									
0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage																									
DO[xx].Error Code [BYTE]	R	Error codes for the digital output channels																								
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital output module</td> </tr> <tr> <td>0x02</td> <td>Channel shutdown due to overload</td> </tr> <tr> <td>0x04</td> <td>Error while reading back the digital outputs</td> </tr> <tr> <td>0x08</td> <td>Error while reading back the status of the digital outputs</td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital output module	0x02	Channel shutdown due to overload	0x04	Error while reading back the digital outputs	0x08	Error while reading back the status of the digital outputs														
		Coding	Description																							
		0x01	Fault in the digital output module																							
		0x02	Channel shutdown due to overload																							
0x04	Error while reading back the digital outputs																									
0x08	Error while reading back the status of the digital outputs																									
DO[xx].Value [BOOL]	W	Output value for DO channels: 1 = output energized 0 = output de-energized																								
		Pulsed outputs must not be used as safety-related outputs!																								

Table 31: ELOP II Factory - Digital Output System Signals

5 Operation

The F30 controller is ready to operate. No specific monitoring is required for the controller.

5.1 Handling

Handling of the controller during operation is not required.

5.2 Diagnosis

A first diagnosis results from evaluating the LEDs, see Chapter 3.4.1.

The device's diagnostic history can also be read using the programming tool.

6 Maintenance

No maintenance measures are required during normal operation.

If a device or module fails, replace it with an identical type or an alternative type which is admitted by HIMA.

Only the manufacturer is authorized to repair the device/module.

6.1 Faults

Refer to Chapter 3.1.1.1, for more information on the fault reaction of digital inputs.

Refer to Chapter 3.1.2.1, for more information on the fault reaction of digital outputs.

6.1.1 Operating System Version 6.42 and Beyond

If the test harnesses detect faults in the processor system, the device is rebooted. If a further internal fault occurs within the first minute after the reboot, the device enters the STOP_INVALID state and will remain in this state. This means that the input signals are no longer processed by the device and the outputs switch to the safe, de-energized state. The evaluation of diagnostics provides information on the fault cause.

6.1.2 Operating System Versions Prior to 6.42

If the test harnesses detect faults in the processor system, the module automatically enters the ERROR STOP state and will remain in this state. This means that the input signals are no longer processed by the device and the outputs switch to the safe, de-energized state. The evaluation of diagnostics provides information on the fault cause.

6.2 Maintenance Measures

The following measures are rarely required for the processor module:

- Loading the operating system, if a new version is required
- Executing the proof test

6.2.1 Loading the Operating System

HIMA is continuously improving the operating system of the devices. HIMA recommends to use system downtimes to load a current version of the operating system into the devices.

Refer to the release list to check the consequences of the new operation system version on the system!

Load the operating system using the programming tool.

Prior to loading the operating system, the device must be in STOP (displayed in the programming tool). Otherwise, stop the device.

For more information, refer to the programming tool documentation.

6.2.2 Proof Test

Test the HIMatrix devices and modules every 10 years. For more information, refer to the Safety Manual (HI 800 003 E).

7 Decommissioning

Remove the supply voltage to decommission the device. Afterwards pull out the pluggable screw terminal connector blocks for inputs and outputs and the Ethernet cables.

8 Transport

To avoid mechanical damage, HIMatrix components must be transported in packaging.

Always store HIMatrix components in their original product packaging. This packaging also provides protection against electrostatic discharge. Note that the product packaging alone is not suitable for transmission.

9 Disposal

Industrial customers are responsible for correctly disposing of decommissioned HIMatrix hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.

Appendix

Glossary

Term	Description
ARP	Address Resolution Protocol: Network protocol for assigning the network addresses to hardware addresses
AI	Analog Input
COM	COMmunication module
CRC	Cyclic Redundancy Check
DI	Digital Input
DO	Digital Output
ELOP II Factory	Programming tool for HIMatrix systems
EMC	ElectroMagnetic Compatibility
EN	European Norm
ESD	ElectroStatic Discharge
FB	FieldBus
FBD	Function Block Diagrams
FTA	Field Termination Assembly
FTT	Fault Tolerance Time
ICMP	Internet Control Message Protocol: Network protocol for status or error messages
IEC	International Electrotechnical Commission
MAC address	Media Access Control address: Hardware address of one network connection
PADT	Programming And Debugging Tool (in accordance with IEC 61131-3), PC with SILworX or ELOP II Factory
PE	Protective Earth
PELV	Protective Extra Low Voltage
PES	Programmable Electronic System
PFD	Probability of Failure on Demand, probability of failure on demand of a safety function
PFH	Probability of Failure per Hour, probability of a dangerous failure per hour
R	Read: The system variable or signal provides value, e.g., to the user program
Rack ID	Base plate identification (number)
Non-reactive	Supposing that two input circuits are connected to the same source (e.g., a transmitter). An input circuit is termed <i>non-reactive</i> if it does not distort the signals of the other input circuit.
R/W	Read/Write (column title for system variable/signal type)
SB	System Bus (module)
SELV	Safety Extra Low Voltage
SFF	Safe Failure Fraction, portion of safely manageable faults
SIL	Safety Integrity Level (in accordance with IEC 61508)
SILworX	Programming tool for HIMatrix systems
SNTP	Simple Network Time Protocol (RFC 1769)
S.R.S	System.Rack.Slot addressing of a module
SW	Software
TMO	TiMeOut
W	Write: System variable/signal is provided with value, e.g., from the user program
WD	WatchDog: Time monitoring for modules or programs. If the watchdog time is exceeded, the module or program enters the ERROR STOP state.
WDT	WatchDog Time

Index of Figures

Figure 1: Connections to Safety-Related Digital Inputs	13
Figure 2: Line Control	14
Figure 3: Connecting Actuators to Outputs	15
Figure 4: Sample Type Label	18
Figure 5: Front View	19
Figure 6: Block Diagram	19
Figure 7: Sample MAC Address Label	23
Figure 8: Label for Ex Conditions	33

Index of Tables

Table 1:	HIMatrix System Variants	7
Table 2:	Additional Relevant Documents	8
Table 3:	Environmental Requirements	11
Table 4:	Part Numbers	17
Table 5:	Operating Voltage LED	20
Table 6:	System LEDs	21
Table 7:	Ethernet Indicators	22
Table 8:	I/O LEDs	22
Table 9:	Ethernet Interfaces Properties	23
Table 10:	Network Ports (UDP Ports) in Use	23
Table 11:	Network Ports (TCP Ports) in Use	24
Table 12:	Connections for Fieldbus Communication	24
Table 13:	Pin Assignment of D-sub Connectors FB1 and FB2 for PROFIBUS DP	24
Table 14:	Pin Assignment of the D-sub Connectors FB1 and FB2 for RS485	25
Table 15:	Pin Assignment of the D-sub Connectors FB1 and FB2 for RS232	25
Table 16:	Pin Assignment of the D-sub Connectors FB1 and FB2 for RS422	25
Table 17:	Pin Assignment of the D-sub Connectors FB1 and FB2 for INTERBUS	26
Table 18:	Pin Assignment of D-sub Connector FB3 for Modbus	26
Table 19:	Product Data	28
Table 20:	Specifications for the Digital Inputs	28
Table 21:	Specifications for the Digital Outputs	29
Table 22:	Product Data F30 011	29
Table 23:	Certificates	30
Table 24:	Terminal Assignment for the Digital Inputs	31
Table 25:	Terminal Assignment for the Digital Outputs	32
Table 26:	SILworX - System Parameters for the Digital Inputs, Module Tab	35
Table 27:	SILworX - System Parameters for the Digital Inputs, DI 20: Channels Tab	36
Table 28:	SILworX - System Parameters for the Digital Outputs, Module Tab	37
Table 29:	SILworX - System Parameters for the Digital Outputs, DO 8: Channels Tab	38
Table 30:	ELOP II Factory - Digital Input System Signals	41
Table 31:	ELOP II Factory - Digital Output System Signals	42

Index

diagnosis.....	43	part number	17
fault reaction		safeethernet	23
digital inputs	14	specifications	29
digital outputs	15	SRS	17
line control.....	14, 16	surge.....	33



SAFETY
NONSTOP

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Tel: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com Internet: www.hima.com

(1025)